



Abbott Analytical

Consulting Scientists to the Disinfectant Industry



Test Report

Product name: Safe4 Disinfectant Cleaner

Batch or ref no: Batch 1999, Best before 9/2/19

Manufacturer or supplier: Safe Solutions (Safe4) Ltd
Wharton Green House, Bostock Road, Winsford, CW7 3BD

Sample ref: 17D/007 **Date received:** 7 April 2017

Date tested: 5 May 2017 **Certificate date:** 11 May 2017

Certificate no: 17D.007VSq.SSL **Page:** 1 of 3

Analysis required: EN 1656:2009, Chemical disinfectants and antiseptics -
Quantitative suspension test for the evaluation of
bactericidal activity of chemical disinfectants and
antiseptics used in the veterinary area - Test method and
requirements (phase 2, step 1)

Storage conditions: Room temperature in darkness

Appearance of product (solution): Dark green liquid

Active substance(s) and their concentration(s): Not disclosed

Notes

The test results in this report relate only to the sample(s) tested.
This test report may not be reproduced except in full, adapted, altered or used
to create a derivative work, without written approval from Abbott Analytical.

D C Watson BSc, CBiol, MRSB

Abbott Analytical Limited
Unit 2, Hickmans Road,
Birkenhead, CH41 1JH, United Kingdom

Registered address: Kemp House, 160 City Road,
London, EC1V 2NX, United Kingdom

Telephone: +44 (0)151 345 6753
email: enqs@abbottanalytical.co.uk
www.abbottanalytical.co.uk

A company registered in England and Wales
Company number 10031406



Abbott Analytical



Consulting Scientists to the Disinfectant Industry

Certificate no: 17D.007VSq.SSL

Date: 11 May 2017

Page: 2 of 3

Experimental conditions

Concentration(s) of product tested: 1:50 & 1:100 v/v

Product diluent: Sterile hard water (300mg/l CaCO₃)

Test organism(s): *Streptococcus equi* subsp *equi*
(DSM 20561)

Contact time(s): 5 min ± 10s

Test temperature: 20°C ± 1°C

Test conditions: High-level soiling

Interfering substance: 10g/l bovine albumin +
10g/l yeast extract

Method: Dilution-neutralisation

Neutralising solution: 30g/l Polysorbate 80 + 3g/l Lecithin +
1g/l L-histidine + 1g/l L-cysteine

Incubation temperature: 36°C ± 1°C

Conclusion

When tested at concentrations of 1:50 and 1:100 this sample of Safe4 Disinfectant Cleaner meets the requirements of EN 1656:2009 for bactericidal activity in 5 minutes at 10°C, under high-level soiling conditions, against the referenced strain of *Streptococcus equi* subsp *equi*.

D C Watson BSc, CBiol, MRSB

Abbott Analytical Limited
Unit 2, Hickmans Road,
Birkenhead, CH41 1JH, United Kingdom

Registered address: Kemp House, 160 City Road,
London, EC1V 2NX, United Kingdom

Telephone: +44 (0)151 345 6753
email: enqs@abbottanalytical.co.uk
www.abbottanalytical.co.uk

A company registered in England and Wales
Company number 10031406



Abbott Analytical



Consulting Scientists to the Disinfectant Industry

Certificate no: 17D.007VSq.SSL

Date: 11 May 2017

Page: 3 of 3

Results: Streptococcus equi subsp equi (DSM 20561)

Validation and controls:

| Validation suspension (Nv _o) | | | Experimental conditions control (A) | | | Neutralizer or filtration control (B) | | | Method validation (C) | | |
|--|----|-------------|---|----|-------------|---|----|-------------|---|----|-------------|
| Vc1 | 46 | \bar{x} = | Vc1 | 44 | \bar{x} = | Vc1 | 42 | \bar{x} = | Vc1 | 48 | \bar{x} = |
| Vc2 | 49 | 47.5 | Vc2 | 38 | 41 | Vc2 | 36 | 39 | Vc2 | 46 | 47 |
| 30 ≤ \bar{x} (Nv _o) ≤ 160 ? <input checked="" type="checkbox"/> yes <input type="checkbox"/> no | | | \bar{x} (A) ≥ 0.5 x \bar{x} (Nv _o) ? <input checked="" type="checkbox"/> yes <input type="checkbox"/> no | | | \bar{x} (B) ≥ 0.5 x \bar{x} (Nv _o) ? <input checked="" type="checkbox"/> yes <input type="checkbox"/> no | | | \bar{x} (C) ≥ 0.5 x \bar{x} (Nv _o) ? <input checked="" type="checkbox"/> yes <input type="checkbox"/> no | | |

**Test suspension:
(N and N_o)**

| | | | |
|-------------------------------------|-----|-----|---|
| N | Vc1 | Vc2 | \bar{x} (wm) = 1.76 x10 ⁸ ; lg N = 8.25 |
| 10 ⁻⁶ | 167 | 184 | N _o = N/10 ; lg N _o = 7.25 |
| 10 ⁻⁷ | 16 | 21 | 7.17 ≤ lg N _o ≤ 7.70 ? <input checked="" type="checkbox"/> yes <input type="checkbox"/> no |
| Control of weighted mean counts (N) | | | Quotient = 9.49 Between 5 and 15 ? <input checked="" type="checkbox"/> yes <input type="checkbox"/> no |

Test:

| Product test conc. | Contact time | Vc1 | Vc2 | N _a = (\bar{x} x10) | lg N _a = | lg R = (lg N _o - lg N _a) | Status |
|--------------------|--------------|-----|-----|--------------------------------------|---------------------|--|--------|
| 1:50 | 5 min | 0 | 0 | < 140 | < 2.15 | > 5.10 | PASS |
| 1:100 | 5 min | 2 | 0 | < 140 | < 2.15 | > 5.10 | PASS |

D C Watson BSc, CBiol, MRSB

Abbott Analytical Limited
Unit 2, Hickmans Road,
Birkenhead, CH41 1JH, United Kingdom

Registered address: Kemp House, 160 City Road,
London, EC1V 2NX, United Kingdom

Telephone: +44 (0)151 345 6753
email: enqs@abbottanalytical.co.uk
www.abbottanalytical.co.uk

A company registered in England and Wales
Company number 10031406